



STRIKER™

HAMMER CHISEL MONTHLY CHUCK MAINTENANCE

Perform the recommended maintenance steps monthly to maintain proper twist lock function of the M18 FUEL™ STRIKER™ Hammer Chisel chuck.

RECOMMENDED MATERIALS

- Oil-based solvent or lubricant
- Rag or towel



BEFORE USING THE TOOL, READ AND UNDERSTAND THE OPERATOR'S MANUAL TO REDUCE THE RISK OF INJURY AND FOR PROPER MAINTENANCE AND CARE.

1. CLEAN

Remove tool of any excess debris. Place tool upright and on a secure work surface.



2. LUBRICATE

Apply oil-based solvent or lubricant inside spindle and the gap between spindle & C-ring.



3. WIPE

Remove any excess oil or lubricant from outside of the chuck.

